

Instruction Guide: ZimpleLay™ Dryback Glue Down LVP Vinyl

Acclimation:

Store the boxes UNOPENED in the room where they will be installed for a MINIMUM of 48hours prior to installation. The temperature must remain constant during the acclimation period and may never exceeding +18°C and +26°C.

The boxes must be stored flat and level at all times. Never store the boxes on their sides.

Installer / Owner Responsibly / Inspection:

Always refer to www.bodenflooring.com for the most current instruction guide and requirements. You must read and fully understand this installation manual before installing the flooring.

The installer of the flooring must carefully examine the flooring to acknowledge acceptance of the color, finish and that there are no product defects before installing. If the flooring is not acceptable at the time of installation, the flooring should not be installed, until the installer or owner are satisfied with the product quality. Once the flooring is installed, it is considered as acceptance by the installer and the owner.

The labels on each carton indicate product color, production number(s) and or date(s). The installer must confirm the product number, production number(s) and or date(s) on the cartons match PRIOR to installation. If there is a discrepancy, it must be resolved before the installation begins.

Operating Ranges / General Limitations:

The product is rated to be installed in INTERIOR only, never be exposed to temperatures which are outside of the range +18°C and +26°C. The environmental temperature must remain between +18°C and +26°C for the life of the product, including during installation.

Windows in rooms which allow direct sunlight to enter must have adequate blinds or window coverings to ensure the surface temperature of the flooring does not exceed +26°C.

The temperature must not be allowed to change more than 3°C per 24 hour period, never exceeding +18°C and +26°C.

Product expansion and contraction (dimensional changes) are an inherent property of Thermoplastic (vinyl) and is to be expected. Exposure to temperatures beyond the allowable min max ranges will result in gapping or peaking in an installed / finished floor.

For this reason it is imperative that installers and customers abide by the minimum / maximum temperature requirements, including the acclimatization requirements, as detailed in the product installation manual, including the use of proper blinds or window coverings.

The use of a Kiesel Resilient flooring adhesive (see “Adhesive” section of this document), applied per Kiesel's requirements has potential to mitigate the effects of dimensional changes within a vinyl product, but cannot fully eliminate it.

Transitions are required at doorways, to allow for contraction / expansion.

Transitions / reducers must be incorporated to protect the exposed edge of flooring from damage, covering the exposed edges of the flooring.

Allow an 8mm gap at the perimeters of each room.

Never install the flooring with an offset that is smaller than the length of the board width.

Change in gloss level, dulling, scratching, scuffing, and chipping, are considered normal wear with the intended use over time as the floor ages.

Adhesive:

Kiesel Resilient flooring adhesive must be used to validate warranty.

Always refer to Kiesel's guidelines to ensure adhesive suitability, sub-floor preparation, correct trowel sizes, rolling requirements, etc.

Basic instruction for the installation of an LVT flooring using a “wet glue” method with Kiesel adhesive involves: 1) spreading glue with a correctly notched trowel 2) immediately installing the planks into the wet adhesive 3) then rolling the floor with a 110lbs (50kg) roller to engage the flooring.

A “wet glue” installation is always recommended to decrease the chance of movement / gapping/ etc in the flooring. Never use “pressure set” installation methods as they do not provide sufficient adhesion and void warranty.

Ensure 100% transfer of the adhesive to the substrate and the underside of the flooring.

General Sub-floor:

The floor must be clean, level, smooth, flat and structurally sound, not to exceed a variation in plane more than 1/8” over 6'. No claims will be honoured if the substrate telegraphs through the flooring.

Wood Sub-floor & Sheeting:

At a minimum the subfloor must be 3/4" (19mm) exterior grade APA rated T&G plywood or Flooring Grade T&G OSB, both with the seams sanded.

A layer of underlayment grade (CANPLY/APA rated) plywood must be fastened ontop of the subfloor, with the underlayment sheets installed perpendicular to the subfloor sheets, fastened according to local building regulations. The sub-floor panels must have a sanded face and sanded seams which are flush with adjacent panels, with a deflection that does not exceed L/360.

The joist system must be designed to support the weight of the flooring being installed. Any patching of the sub-floor must be done according to patching manufacturers requirements.

Concrete Sub-floor:

Concrete must have a minimum compressive strength of 3500 psi. Moisture vapour transmission levels can not exceed 5lbs / 1000sqft / 24 hours (2.3kg / 92.9m2 / 24hours) per ASTM F-1869.

Prepare / repair all cracks prior to installation.

Saw cuts / expansion joints in the concrete must be honoured.

Renovation (over existing flooring's):

The flooring can not be installed over flooring's which have a MOH less than 7. Ie cushion vinyl, vinyl floors of multiple layers, carpet, etc.

If installing over existing tile flooring, the grout joints must be flush with the surface of the tile. The grout joints can be done using a suitable patching compound.

Care and Maintenance:

Only use cleaners which have PH neutral formula, which are specifically designed for vinyl flooring.

Never use abrasive pads, etc to clean the flooring.

Remove any spills immediately.

Chairs, stools, furniture, etc must have appropriate protective pads at their contact point with the floor, to ensure the flooring is not damaged. If the furniture has wheels, the wheels must be soft and tested to ensure they do not damage the flooring.

The flooring should be protected with appropriate temporary jobsite protective covering during construction to prevent damage.

Use vinyl compatible doormats at entrances to prevent unnecessary wear from abrasives like sand, mud, etc. Trapped sand or abrasives under the rug can scratch the floor.

The mat/rug must be confirmed to be compatible with vinyl flooring, as some rugs/mats with rubber (synthetic or natural rubber) backings can leave permanent stains or markings on vinyl. Some PVC backed rugs can have adhesives which leave residue on vinyl.